



# DUALCOM PRO 2 RANGE

## STEP 4 - TESTING

# DualCom Pro 2 Range

## Step 4 - Testing

Before leaving site you must test the DualCom Pro 2 device as per these steps.

- a** - Place device on test at the ARC and send a range of signals from the panel
- b** - Perform a path test by tapping button C whilst in quiescent/normal state
- c** - LED 3 will flash to show signals are being sent
- d** - Check signals are received at the ARC

You should also simulate path failures at part of the testing process.

- a** - Place device on test at the ARC
- b** - Whilst in the quiescent/normal state section, press button A to get to the connectivity menu. The LEDs (LED 1 = single-path, LED 1 & 2 = dual-path) will be lit
- c** - Hold button B for 5 seconds. Once let go, LED 1 will go red to show path 1 is in simulated fail
- d** - For dual-path devices, hold button C for 5 seconds. Once let go, LED 2 will go red to show path 2 is in simulated fail. Check signals are received at the ARC
- e** - Tap button B & C to restore each path. LEDs 1 and/or 2 will go green. Check path failure signals are received at the ARC

**IF YOU HAVE PURCHASED A DUAL-PATH DEVICE, YOU MUST ENSURE BOTH PATHS ARE CONNECTED BEFORE LEAVING SITE.**





**IF YOU DISCONNECT BOTH PATHS AT THE SAME TIME, MY BASE WILL ONLY SHOW THE FIRST PATH IN FAILURE. THIS IS EXPECTED BEHAVIOUR.**





### MY BASE APP





My Base provides Installers with the ability to manage and configure DualCom Pro 2 devices on a handy App/Web portal.



Simply download CSL My Base from your appropriate App store and obtain log-in information from CSL

(or the CSL web administrator within your company) to access these great features:

View path status 	Check signal strength 	View panel connection status 	Configure static IP information 
---	--	---	--

Amend panel connection 	Change pin configuration 	Check ATS path availability 	Remotely upgrade device firmware 
---	---	--	---




View Alarms (you must still check with your ARC that alarms are being received by them) 	Test Alarm 	Invert fault relay 	Configure outputs 
---	--	--	---

Amend Smart Reporting 	Add estate name 
--	--

## LEDS & TROUBLESHOOTING

*Figure 9 - Commissioning LEDs*

As the DualCom Pro 2 powers up for the very first time it will run through a commissioning process. You will need to wait for LEDs 1, 2 & 3 to go green before the unit reboots.

LED 1	LED 2	LED 3
 No light = No power	 Red flashing = No comms	 Red flashing = No comms








 Red flashing = Power Start Up	 Amber solid = 1 path comms (dual-path systems)	 Amber flashing = Comms path found
 Green solid = Power On	 Green solid = All paths comms (dual-path systems)	 Amber solid = Commissioning server found. Contacting alarm server
		 Green solid = Fully Commissioned

Figure 10 - Quiescent/Normal State LEDs

Once commissioned, the unit will return to its quiescent/normal state. Only LED 3 should be visible and will show you whether the unit has any errors or is transmitting data.








LED 3
 Red solid = Error found on the device (no commissioning performed)
 Amber flashing = Only one path is working on the dual-path system and the device is currently transmitting or receiving data (pdp context active)
 Amber solid = Only one path is working on the dual-path system, however it is able to transmit & receive data
 Green flashing = No errors found and the device is currently transmitting or receiving data (pdp context active)
 Green solid = No major errors found

Figure 11 - Connectivity Section

To toggle between the connectivity section and quiescent/normal state press button A. Single-path systems will only show LED 1. Dual-path systems will show both LEDs 1 & 2. LAN data transmission is covered by the ETH LED.

LED 1	LED 2
 Red flashing = No signal / SIM not ready or LAN not connected	 Red flashing = No signal / SIM not ready or LAN not connected







 Amber flashing = Registering / Signal is unacceptable / LAN connected but cannot transmit data	 Amber flashing = Registering / Signal is unacceptable / LAN connected but cannot transmit data
 Green flashing = Signal is acceptable (3/10) but could be improved	 Green flashing = Signal is acceptable (3/10) but could be improved
 Green solid = Signal 4/10 (or above) or LAN connected	 Green solid = Signal 4/10 (or above) or LAN connected

Figure 12 - Simulate Path Fails (testing the system)

It is possible to simulate a path fail for the primary and secondary path. Once in the connectivity section, press and hold B to fail the primary path and/or C to fail the secondary path. The path will stay in fail for 15 mins unless you tap B or C again.










LED 1	LED 2
 Red flashing = Interface in fail mode	 Red flashing = Interface in fail mode
 Green flashing = Interface tx/rx data	 Green flashing = Interface tx/rx data
 Green solid = Interface out of fail mode	 Green solid = Interface out of fail mode

Figure 13 - Additional LEDs

There are 3 additional LEDs shown as BUS, PNL and ETH.

LED 1	LED 2	LED 3
BUS	RS422 connection to additional accessories (i.e remote radio module)	 Green/Amber flashing = Data is being transferred
PNL	Serial connection to panel	 Green/Amber flashing = Data is being transferred
ETH	LAN connection to customer's router	 Green/Amber flashing = Data is being transferred

## RADIO TROUBLESHOOTING

**How can I fail my signalling paths without having to disconnect them?**

To fail each path enter the connectivity menu (see simulate path fail section - Figure 12 above). Press and hold B to fail the primary path or C to fail the secondary path. The path will stay in fail for 15 mins unless you tap B or C again to restore the applicable path.

### **How can I check the signal strength of each radio module?**

You can check the signal strength of each radio module on a commissioned device via the My Base App. Alternatively, when in the quiescent/normal state, you can press button A to toggle to the connectivity menu. Once there, LED 1 (first path) & LED 2 (second path) will show you the signal strength. We recommend a solid green LED (40% or 4/10).

### **Does my unit have a roaming SIM?**

Yes, all DualCom Pro 2 devices come with at least 2 Roaming 4G SIMs

### **My signal strength is less than 30% (3/10) or my LED is orange/red. What can I do to improve it?**

For all radio variants:

- Avoid coiling the aerial cable
- Move the aerial away from electrical equipment/wiring
- Move the aerial to a higher point in the property or closer to a window/door