

PANEL GUIDE

Scantronic 8136 – Dial Capture

Updated March 17, 2025

Latest information

<https://www.csl-group.com/panel-guides/eaton/scantronic-8136/>

Panel Connection – Dial Capture

Manufacturer	Cooper Safety/Eaton
Model	Scantronic 8136
Minimum Panel Firmware	V5.1
Cable required?	MCM connected to: • DualCom Pro 1 – MCM plug-on module CS.1.402 • DualCom Pro 2 – DI & AL
Panel Connection	Dial Capture

DualCom Pro to Panel Wiring

DualCom Pro 1 – MCM plug-on module – Line A DualCom Pro 2 – DI	PSTNA
DualCom Pro 1 – MCM plug-on module – Line B DualCom Pro 2 – AL	PSTNB

Panel Configuration

- (Menu>)= X key
- (Enter) = Tick key

- Default Keypad User code = 1234 (Menu)

Panel Login

1. [0 Installer Programming] will be displayed, press (Enter)
2. [00 Program System] will be displayed, input 71
3. [71 Communication options] will be displayed, press (Enter)
4. [Dial Type] will be displayed, set to 'DTMF' and press (Enter)
5. [Call Mode] will be displayed, set to 'Single' and press (Enter)
6. [3 Way Call] will be displayed, set to 'Disabled' and press (Enter)
7. [Dynamic Test] will be displayed, set to 'Disabled' and press (Enter)
8. [Static Test] will be displayed, set to 'Disabled' and press (Enter)
9. [Line Integrity] will be displayed, set to 'Disabled' and press (Enter)
10. [Line Monitor] will be displayed, set to 'Enabled' and press (Enter)
11. [Report Restorals] will be displayed, set to 'Enabled' and press (Enter)
12. [Log with Partns] will be displayed, set to 'Enabled' and press (Enter)
13. [Format] will be displayed, set to 'Extended SIA 3' and press (Enter)
14. [SIA Tone Format] will be displayed, set to 'Bell 103' and press (Enter)
15. [Report Mode] will be displayed, set to 'Full' and press (Enter)
16. [TA->BA] will be displayed, set to 'Enabled' and press (Enter)
17. [Acknowledge] will be displayed, set to 'Tonal' and press (Enter)
18. [71 Communication options] will be displayed, input 72
19. [72 Program Phone Numbers] will be displayed, press (Enter)
20. [T01: Number=] will be displayed, press (Enter)
21. Input a random telephone number, press (Enter)
22. Note: number must NOT be '123456'
23. [T01: Account No] will be displayed, press (Enter)
24. Input account or site ID, press (Enter) twice

Panel Setting for UDL

1. The panel's call-back feature requires enabling successful UDL communications.
2. After engineer login.
3. [0 Installer Programming] will be displayed, press (Enter)

4. [00 Program System] will be displayed, input 73
5. [73 Downloader Options] will be displayed, press (Enter)
6. [Account Name] will be displayed
7. Input account name, and press (Enter). Note: The account name must match what is stored in the UDL application
8. [Rings to Answer] will be displayed, Input 1, press (Enter)
9. [Answer on 1 Ring] will be displayed, set to 'Disabled', press (Enter)
10. [Secure Callback] will be displayed, set to 'Enabled', press (Enter)
11. [T01:Download No] will be displayed, press (Enter)
12. Input '123456', press and then press (Menu)