

DualCom Pro Vanderbilt SPC 4300



Panel Connection – MCM

Manufacturer	Vanderbilt
Model	SPC 4300
MCM	MCM version greater or equal to V1.06
Panel Firmware Range	V2.1.0
Cable Required?	MCM
Panel Profile	VANDERBILT-SPC-MCM
Panel Bus Connection	None
Technical Notes	See below

Panel Connection Information

DualCom Pro MCM	Vanderbilt (PC137421 MCM Unit)
A	B
A	B

Panel Programming

- Default Keypad Login code = 1111
- Login to panel > "Full Engineer" will be displayed > Press "Select" button > "System Status" will be displayed
- Scroll down menu until "Communication" is displayed > Press "Select" button
- Scroll down menu until "Modems" is displayed and press "Select" button > "Primary" is displayed > Press "Select" button
- "Enable Modem" is displayed > Press "Select" button to set modem to be enabled
- Scroll down menu until "Country Code" is displayed > Press "Select" button to set to UK
- Scroll down menu until "Answer Mode" is displayed > Press "Select" button to set to numbered rings of 1 ring
- Scroll down menu until "Line Monitoring" is displayed > Press "Select" button to set mode to "Disabled"
- Press "Back" button until "Primary" is displayed > Scroll down menu until "Backup" is displayed > Press "Select" button to disable the backup modem
- Press the "Back" button until "Modems" is displayed > Scroll down menu until "Central Station" is displayed > Press "Select" button
- "Add" will be displayed > Press "Select" button to create a new "Central Station" account
- Input account ID > Press "Enter" button. (Press and hold button for number input)
- Input account name > Press "Enter" button > Select [SIA] as the protocol to use > Press "Select" button
- Input the 1st "Phone Number" > Press "Enter" button > Clear 2nd "Phone Number" and press "Enter" button
- Press "Back" button until "Central Station" is displayed
- Scroll down menu until "Remote Maint." is displayed > Press "Select" button to enable "Remote Maintenance"
- Scroll down menu until "ID" is displayed > Press "Select" button > Input ID
- Scroll down menu until "Password" is displayed > Press "Select" button > Input password
- Scroll down menu until "In Conns. Setts" is displayed > Press "Select" button > Disable IP
- Press back until "Remote Maint" is displayed > Scroll down menu until "SPC Pro" is displayed > Press "Select" button
- Enable access, and input ID and passwords > Disable IP > Press "Back" until no longer in "Engineer Mode"